

SET-UP RECOMMENDATIONS

● AIR CONDITIONING

- constant temperature of 23 – 27°C
- relative humidity below 50 %
- proper air ventilation

● POSITIONING OF THE MACHINE

- solid, level ground
- vibration-free environment
- 1 m radius of free space around the machine for service purposes

● YELLOW OR RED LIGHT ROOM CONDITIONS

- colored fluorescent tubes
- foils on windows
- no light with a wave length < 500 nm in the environment of the machine

● ELECTRICAL CONNECTION AVAILABLE

230 V, 16 A (USA: 120V / 60Hz, 15A)

● ETHERNET CONNECTION AVAILABLE

● AVAILABILITY OF PRESSURIZED AIR

dry and free from oil

● AVAILABILITY OF A WORKPLACE

for cleaning purposes (post processing)