

# SET-UP RECOMMENDATIONS FOR CERAFAB® SYSTEMS

## AIR CONDITIONING

- constant temperature of 23 – 27°C
- relative humidity below 50 %
- proper air ventilation

## POSITIONING OF CERAFAB® SYSTEMS

- solid, level ground
- vibration-free environment
- 1 m radius of free space around the machine for service purposes

## YELLOW OR RED LIGHT ROOM CONDITIONS

- colored fluorescent tubes
- foils on windows

## UPS – UNINTERRUPTIBLE POWER SUPPLY DEVICE

protects peripherals connected to the power network in case of power outage and overvoltage

## ELECTRICAL CONNECTION AVAILABLE

230 V, 16 A (USA: 120V / 60Hz, 15A)

## ETHERNET CONNECTION AVAILABLE

## AVAILABILITY OF PRESSURIZED AIR

dry and free from oil

## AVAILABILITY OF A WORKPLACE

preparing CeraFab® Systems for cleaning & post-treatment

**Optional:**  
Cera Cleaning Station Ultra®